

# Activeer uw myPOS-pakket



## Vóór het activeren, moet u:

- Uw myPOS-apparaat verbinden met het internet via Bluetooth, Wi-Fi of GPRS
- Internet browser voor toegang tot mypos.com
- Mobiele telefoon (die sms kan ontvangen)

## Aan de slag

myPOS Data simkaart is helemaal GRATIS voor u en u ontvangt er één voor elk myPOS-terminal. Wij hebben uw connectiviteit gezekerd!

1. Ga naar mypos.com en log in op uw myPOS-account.
2. Ga naar menu **Apparaten** → **Activeer uw apparaat**.  
  
Selecteer uw apparaat instellingen en een activeringscode wordt weergegeven in uw myPOS-account.
3. Na invoering van de verkregen activeringscode is uw apparaat gereed voor gebruik. Klik op "ik ben klaar met het activeren" en u bent klaar!
4. Optioneel - Activeer uw gratis myPOS prepaid businesskaart en krijg direct toegang tot uw geld.

## Succesvolle activering

Gefeliciteerd! Uw myPOS-terminal is geactiveerd en klaar voor gebruik. U krijgt toegang tot uw e-Money account op [mypos.com](https://mypos.com) of van de myPOS

The image shows three sequential screenshots of the myPOS activation process:

- Step 1:** The myPOS website homepage. It features a navigation bar with 'INDUSTRIES', 'PRODUCTS', 'PARTNERS', 'DEVELOPERS', 'ABOUT', and 'SHOP'. A 'Login' button is in the top right. The main content area includes a 'United Kingdom' dropdown menu, a 'Join myPOS now and start accepting payments from all your sales channels in one single platform.' message, and a list of benefits: 'No set up or monthly and annual fees', 'Rock-solid security and fraud protection', 'Instant worldwide money transfers', and 'Wide range of value-added services'. A 'CREATE ACCOUNT' button is at the bottom.
- Step 2:** The 'Activate Device' screen. It has three steps: 'STEP 1 ENTER DEVICE SETTINGS', 'STEP 2 ENTER OUTLET SETTINGS', and 'STEP 3 REVIEW AND CONFIRM'. The current step shows fields for 'Enter device identifier \*' (with radio buttons for 'Serial Number' and 'Box barcode'), 'Enter device custom name', 'Select your device's currency \*', and 'Choose settlement account \*'. A 'Continue' button is at the bottom right.
- Step 3:** The 'DEVICE ACTIVATION' screen. It shows 'ENTER ACTIVATION CODE' with a text input field and '(X) CANCEL' / '(O) CONFIRM' buttons. A 'Software update' dialog box is overlaid, showing 'Checking for update...' with a progress indicator. A second 'Software update' dialog box shows 'SUCCESSFUL UPDATE Press any key to shutdown the device and then switch it on again.'

app beschikbaar voor Android en iOS. Voor meer informatie of hulp kunt u terecht op: [mypos.com](https://mypos.com)